

G-Printec, Inc.

Doc KAB-T773S-001

1<sup>st</sup> edit Aug 4<sup>th</sup>,2023

CX-D80H/CX-D80 Card Printer

# USB Driver Update Tool Manual

G-Printec

## Overview/Precautions

The USB Driver Update Tool (hereinafter referred to as "this tool") updates the USB drivers for the CX-D80H and CX-D80. This tool package contains several files. Please do not change the folder structure. If you wish to use our printer driver, first install the printer driver using the CD-ROM after deactivation of core isolation. After installation, use this tool to update the USB driver. (If you have your own printer driver developed by yourself, you need not to install this printer driver.)

The USB driver update tool for CX-D80H and the USB driver update tool for CX-D80 are in separate packages. Please be careful not to make a mistake.

If you need to activate core isolation, please turn on after all process are completed.


## Operating Environment

- Microsoft Windows 11
- Microsoft Windows 10 32bit/64bit

## Update Procedure

Case 1. You use CX-D80's original USB driver and printer driver.

### 1. Click "Setup.exe"




### 2. Press "Yes" when the <User Account Control>screen appears.

G-Printec, Inc.

3. [Update Start]screen appears.

- USB driver update will be started
- The old USB driver will be uninstalled, if it is installed.




4. Check the following information and click "OK"

- All printers are turned off.
- All applications are closed.
- No documents are being process for printing (If there is any document being printed, please wait until it finishes printing.)

5. The [ PC restart] screen appears.

- To update the USB driver, it is necessary to restart the PC.
- After restarting the PC, the update will continue automatically.




6. After checking and confirming the following , press "OK" to restart the PC.

- All files are closed.
- All applications are closed.

7. The [Rstart Notification] screen will appear.

- The PC will automatically restart after 120 seconds.



8. If you want to restart your PC immediately, press [Restart now].

9. PC will be restarted .


1 0. Log-in Windows

1 1. Please wait a moment until the tool is restarted.

1 2. When the [User Account Control] screen appears, press [Yes].

1 3. [The "Update Complete"] screen appears.

USB driver has been successfully updated.



**【When printer driver has been installed】**

After 13, please do the following:

- 1.Connect the PC and the printer via USB and turn on the printer.
- 2.Restart the computer after a few minutes. The updated USB driver comes to be reflected in the printer driver. Reflection status can be confirmed in "Device manager". If "CX-D80\_WinUSB U\*\*" appears in Universal serial bus device, driver's update is succeeded. If "CX-D80 U\*\*" appears , river's update is succeeded. Please try again.

Case 2. You use CX-D80's original USB driver and your own or third party's printer driver.

If you already downloaded CX-D80's existing USB driver, please implement 1-13 in above.

If you newly use CX-D80, please implement 1-4 above.

Since the old USB driver is not installed, steps 5 through 12 are not required.

Therefore, the PC's restarting is not executed.